

## **Setting the Exakta shutter**

### **Short or very long exposure times**

Cock the shutter, don't wind the long time mechanism, (if you do, it will unwind uselessly) and set the short times knob on

- the required time for short times
- B for press-to-open > let-go-to-shut
- T/Z for press-and-let-go-to-open > press-and-let-go-to shut

### **Long exposure times**

Cock the shutter, wind the long time mechanism, set the short times knob on B or T/Z and select a long time (in black) on the long times knob. Releasing now will produce the chosen long time. Maximum exposure 12 seconds.

### **Short exposure times with self timer**

Cock the shutter, wind the long time mechanism, choose a short time on the short times knob, set the long times mechanism on any red time.

Releasing now will produce a short exposure time with self timer.

### **Long exposure times with self timer**

Cock the shutter, wind the long times mechanism. set the short times knob on B or T/Z, select a time-with-self timer (one of the red settings).

Releasing will now produce a long exposure time with self timer. Maximum 6 seconds exposure.